



[Embedded Pico Systems]

User Manual

USB2TCM interface

Classification: **Confidential**

Document Revision: **A**

© MpicoSys – 2013

All rights reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner.

Table of Contents

1	<u>Introduction</u>	3
2	<u>Supported devices</u>	3
3	<u>Supported operating system</u>	4
4	<u>Usage</u>	4
4.1	<u>First connection</u>	4
4.2	<u>Uploading image to TCM</u>	6
4.3	<u>Image conversion to EPD format</u>	6
5	<u>Troubleshooting</u>	8
6	<u>Revision History</u>	9
7	<u>Legal Information</u>	10
7.1	<u>Disclaimers</u>	10
8	<u>Contact Information</u>	11

1 Introduction

This document describes features and usage of USB2TCM interface (Figure 1.1) - easy to use USB Mass Storage device, which allows uploading images from PC to TCM module directly.




Figure 1.1: USB2TCM interface

2 Supported devices

USB2TCM was designed to interface PC and following TCM modules:

- TCM-P441_v1.1 (Figure 2.1)
- TCM-P74-110_v1.1 (Figure 2.2)
- TCM-P74-220_v1.1 (Figure 2.2)




Figure 2.1: USB2TCM interface connected to TCM-P441



Figure 2.2: USB2TCM interface connected to TCM-P74

3 Supported operating system

Device was developed and tested on Microsoft Windows 7 Professional 32bit.

4 Usage

4.1 First connection

When connected to a PC the device behaves as a typical flash drive. At the first connection the device has a capacity of 76kB.

The device needs to be formatted under Windows environment. A prompt window should appear after the device is plugged-in in a USB port for the first time.




Figure 4.1: Warning before disk formatting

Press Format disk button.




Figure 4.2: Format Disk options window

There is no need to change any option in the “Format Removable Disk” window. Press the Start button.



Figure 4.3: Windows warning before formatting

Windows will warn, that all data will be erased. Press OK.




Figure 4.4: Format complete

After formatting device is visible as a 56kB flash drive.

4.2 Uploading image to TCM

Connected to the PC the USB2TCM device acts like a Flash Drive. Images in .EPD format¹ can be copied on that drive and will be automatically send to TCM, where the display will be updated.

Procedure is as follow:

- 1) Connect USB2TCM device to PCs USB port and to TCM module
- 2) Check whether PWR LED on USB2TCM module is on
- 3) Check whether USB2TCM device is properly recognized and mounted by Windows (it should be visible as Removable Disk with 56kB free space)
- 4) Copy an image in .EPD format suitable for TCM module used (P441 or P74), to the removable disk
- 5) After copying, the USB2TCM will forward this image to the TCM, which is indicated by the COM LED light (USB2TCM module will reconnect to the host PC during this operation)
- 6) If image was sent correctly, COM LED will turn OFF. If there was erroneous TCM module operation – COM LED will blink until device will be restarted.
- 7) Remove previously sent image from USB2TCM Removable Disk before uploading the new one.

NOTE: if the COM LED continues blinking the transfer from the USB2TCM Module to the TCM failed. The USB2TCM must be reset by power cycling – disconnecting and reconnecting the USB cable.

4.3 Image conversion to EPD format

Image in typical PC format like JPEG or PNG can be converted to EPD by using Convert tool provided by MpicoSys.

Package with tool should be unpacked in convenient location. Run Convert_v3 application. Figure 4.5 shows Convert application for TCM-P441. For TCM-P74 application looks the same only name in top bar is different - ConvertPDI74.

¹ “Timing Controller Solutions for Pervasive Displays 4.41” and 7.4” Panels – Developer's Guide”, Document reference: 0874/13-MK, chapter 6. MpicoSys



Figure 4.5: Convert application for TCM-P441

To convert an image simply drag and drop it on Convert window area. Application will create directory with output files in the same location as the origin image.

Output folder contains four files:

- PDIxx_ImageName_1bit.epd – file with image converted to EPD format
- PDIxx_ImageName_1bit.h – C-type header file, an array with bytes corresponding to the image pixels
- PDIxx_ImageName_1bit.png – png image file in 1-bit colour scale – for preview on PC
- PDIxx_ImageName_4bit.png – png image file in 4-bit colour scale – for preview on PC

, where xx – display type, for which image is created (PDI74 or PDI441), *ImageName* – name of origin image file.

File, which is suitable to send to TCM is the one with extension *.epd. Sample EPD files for TCM-P441 and TCM-P74 will be provided by MpicoSys.

5 Troubleshooting

Issue	Possible causes	Fixes
USB2TCM device is not visible on PC	USB A-mini USB cable damage	Check whether PWR LED on USB2TCM board is on. Replace USB A-mini USB cable.
COM LED is constantly blinking	Problem with TCM module connection	Check connection between USB2TCM and TCM boards. Restart USB2TCM board by USB cable disconnecting and connecting again.
Picture on TCM display is distorted	EPD file uploaded to TCM is not appropriate for used TCM panel	Ensure, that EPD file is according to used panel. Use sample EPD files provided by MpicoSys to verify proper system operation.
EPD file can't be copied on USB2TCM drive – not enough space	USB2TCM memory is occupied	Delete previously send EPD file from USB2TCM removable disk.

6 Revision History

Document Revision	Release Date	Document Status	Supersedes
A	12-08-2013	Draft	–

Table 6.1: Revision history

Document Revision	Change Log
A	Initial version

Table 6.2: Change log

7 Legal Information

Draft

The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. MpicoSys does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

Short data sheet

A short data sheet is an extract from a full data sheet with the same product type number(s) and title. A short data sheet is intended for quick reference only and should not be relied upon to contain detailed and full information. For detailed and full information see the relevant full data sheet, which is available on request via the local MpicoSys sales office. In case of any inconsistency or conflict with the short data sheet, the full data sheet shall prevail.

Data sheet

A document intended to give a full description of the product details that a customer needs to implement the product in their design.

7.1 Disclaimers

General

Information in this document is believed to be accurate and reliable. However, MpicoSys does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

Right to make changes

MpicoSys reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use

Product described in this document is intended for development purposes only and comes without any warranty. MpicoSys accepts no liability for inclusion and/or use of MpicoSys products in commercial products or applications and therefore such inclusion and/or use is at the customer's own risk.

Any software is provided "as is" and any expressed or implied warranties are disclaimed. In no event shall MpicoSys be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to, procurement of substitute goods or services; loss of use, data, or profits; or business interruption) however caused and on any theory of liability, arising in any way out of the use of the software.

Applications

Applications that are described herein for any of these products are for illustrative purposes only. MpicoSys makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Absolute maximum ratings

Stress above one or more limiting values of Absolute Maximum Ratings System (as defined in the Absolute Maximum Ratings System of IEC 60134) may cause permanent damage to the device. Limiting values are stress ratings only and operation of the device at these or any other conditions above those given in the Characteristics sections of this document is not implied. Exposure to limiting values for extended periods may affect device reliability.

Terms and conditions of sale

MpicoSys products are sold subject to the general terms and conditions of commercial sale, as published at <http://www.mpicosys.com/terms>, including those pertaining to warranty, intellectual property rights infringement and limitation of liability, unless explicitly otherwise agreed to in writing by MpicoSys. In case of any inconsistency or conflict between information in this document and such terms and conditions, the latter will prevail.

No offer to sell or license

Nothing in this document may be interpreted or construed as an offer to sell products that is open for acceptance or the grant, conveyance or implication of any license under any copyrights, patents or other industrial or intellectual property rights.

8 Contact Information

For additional information please visit mpicosys.com.

Please contact sales@mpicosys.com for commercial information.

For technical support please contact your supplier.